

Installation of 300 SERIES Sidelight Vertical Mullion

- 1) Install Mullion
 - a. Assemble the Glazing channel and Sidelight Glazing per Cross Section V.
 - b. Mark the desired location of the Mullion on the Header and on the Base Blocking.
 - c. Mount the F Clips (2 each) shown in Joint Detail 22 to the Mullion on one face only.
 - d. Position the Mullion between the Header and Base Blocking and secure the top F Clip only.
 - e. Check for plumb (Vertical Level).
 - f. Install Glazing Base on to Blocking.
 - g. Install the remaining F Clips (4 each) on the Base and Vertical Mullion.
 - h. Return to the Installation Instructions for the relight.

- 2) Install Vertical Mullion Trim (Install after Header and Sill Trim has been installed.)
 - a. Locate the Vertical Mullion Trim. (2 each pieces, square cut at both ends)
 - b. Measure the required length needed and cut the Vertical Mullion Trim, if necessary.
 - c. Install per Cross Section V.

